

DuPont™ Vertrel® MCA

Specialty Fluid

Application Brief

Oxygen Service Cleaning

Vertrel® MCA is a proprietary azeotrope of Vertrel® XF hydrofluorocarbon and trans-1,2-dichloroethylene. It has zero ozone-depletion potential and is ideally suited for oxygen service cleaning applications.



Oxygen service cleaning is more critical than other cleaning applications. Particles left as a residue may hinder operation of valves, sensors, and controls or otherwise cause excessive friction in moving parts. Friction causes heat and may be a potential ignition source. Another concern is explosion potential. Combustible materials ignite more rapidly in an oxygen rich atmosphere. Particles and residual hydrocarbons have a high potential for explosion in an oxygen atmosphere. Some metals may burn in the presence of an ignition source in an oxygen atmosphere. Cleanliness requirements may differ depending on fixed or moving surfaces coming in contact with oxygen and whether the oxygen is in the form of a liquid or a gas. Oxygen service cleaning is more critical and demands the use of a solvent that is oxygen compatible.

Vertrel® MCA is listed by the Compressed Gas Association (CGA) in its "Directory of Cleaning Agents for Oxygen Service." Vertrel® MCA also meets LOX (liquid oxygen) mechanical impact testing requirements in accordance with NFEN 1797, and is approved by major gas producers for use in oxygen systems. ASTM G93 lists Vertrel® MCA in "Standard Practice for Cleaning Methods in Oxygen Enriched Environments."

The U.S. Environmental Protection Agency (EPA) has approved the components of Vertrel® MCA as acceptable under the Significant New Alternatives Policy (SNAP) program as replacements for ozone depleting substances.

Items cleaned include:

- Pipe
- Hoses
- Flow valve assemblies
- Manifolds
- Pumps, compressors and diaphragms
- Heat exchangers
- Cylinders and containment vessels
- Instrument valves
- Regulators
- Tubing
- Flow meters
- Safety relief valves

Cleaning Methods

Components may be cleaned with alternate methods. A cleaning process for component parts used in oxygen service requires a sequence of methods for cleaning, rinsing, and drying. The sequence applies to not only new and refurbished parts, but also to field maintenance cleaning. The critical nature of oxygen service cleaning and the required degree of cleanliness determine the process sequences necessary to accomplish a desired level of cleanliness. Vertrel® MCA can be used in any of the following cleaning methods. These methods individually or sequentially define a cleaning process.

Wiping

Easy access, flat surfaces may be cleaned with a solvent-moistened, lint-free cloth. The wiping method is used when surfaces are large and other methods are impractical to use.

Flushing

Flushing forces solvent through or upon the surface to be cleaned with a sufficient flow rate to remove residual contamination. This method is typically used as a final rinse, after a preliminary cleaning process and before drying.

Immersion

In this method, components are submerged in solvent for a specified time to dissolve and lift surface contaminants. Solvent agitation and ultrasonic energy are often used to dislodge particles and break up difficult-to-remove soils.

Spraying in glove box environments is also used. This method is often used for a first pass, preliminary cleaning process.

Vapor Degreasing

This method uses the vapors of heated solvent to remove contaminants from intricate, irregular, and hard-to-access locations. Spraying with vapor condensation is also used to further remove contaminants from surfaces. In a typical two-ump degreaser, components are rinsed in pure solvent condensate with ultrasonic energy to remove fine particulate. As the parts equilibrate to the temperature of the solvent vapor, condensation ceases and the parts are clean, dry, and safe to handle. This method typically combines all steps necessary for cleaning, rinsing, and drying.

Typical Material Surfaces

- Stainless steel
- Copper
- Seals
- Low carbon steel
- Threaded pipe
- Gaskets

Soils and Contaminants

- Particulate matter
- Hydrocarbon oils
- Lubricants
- Handling soils
- Water contaminants
- PFPE oils & greases

Major Advantages of Vertrel® MCA

- Meets LOX mechanical impact test (NFEN 1797)
- Low residue
- Excellent solvent penetration
- Fast and thorough drying
- Approved by major gas producers and OEMs
- Listed by the CGA in its "Directory of Cleaning Agent for Oxygen Service"
- Listed in ASTM G93, "Standards Practice for Cleaning Methods in Oxygen Enrich Environments"
- U.S. EPA SNAP Approved
- Solvent can be recycled by TMC Industries
- Chemically stable
- Environmentally preferred
- Low in toxicity

Disadvantage of Other Cleaning Systems

- Aqueous wash
 - Poor grease cleaning strength
 - Long soak times
 - Poor surface penetration
 - Long drying time
 - Large potential for rust
 - High energy consumption
 - Difficult to use for field maintenance
 - Long cleaning cycles
- Isopropyl alcohol
 - Flammable
 - Requires extensive venting
 - High disposal costs
 - Photochemically reactive
- Trichlorethylene
 - Hazardous composition
 - Extensive venting required
 - Banned in some states due to high photochemical reactivity
 - High disposal costs

To purchase or learn more contact:



TMC Industries, Inc.
1423 Mill Lane, Waconia, MN 55387
800-772-8179 / 952-442-1140
sales@tmcindustries.com
www.tmcindustries.com

Copyright © 2008 DuPont or its affiliates. All rights reserved. The DuPont Oval Logo, DuPont™, The miracles of science™, and Vertrel®, are registered trademarks or trademarks of E. I. du Pont de Nemours and Company or its affiliates.

The information set forth herein is furnished free of charge and is based on technical data that DuPont believes to be reliable. It is intended for use by persons having technical skill, at their own discretion and risk. The handling precaution information contained herein is given with the understanding that those using it will satisfy themselves that their particular conditions of use present no health or safety hazards. Because conditions of product use are outside our control, we make no warranties, express or implied, and assume no liability in connection with any use of this information. As with any material, evaluation of any compound under end-use conditions prior to specification is essential. Nothing herein is to be taken as a license to operate under or a recommendation to infringe any patents.

CAUTION: Do not use in medical applications involving permanent implantation in the human body or contact with internal body



The miracles of science™